


# MATERI TRAINING INLET

## **CONTROL PLAN**



**PRODUCTION TRAINING**

## **FMEA ( FAILURE MODE AND EFFECT ANALYSIS )**

adalah suatu prosedur terstruktur untuk mengidentifikasi dan mencegah sebanyak mungkin mode kegagalan (*failure mode*).

FMEA digunakan untuk mengidentifikasi sumber-sumber dan akar penyebab dari suatu masalah kualitas.

### **❑ Control Plan**

adalah Sistem pengontrolan pada suatu proses yang dilakukan oleh Process Control, Operator dan Leader atau Supervisor

### **❑ Manufacturing Specification**

adalah Batasan atau spesifikasi suatu produk yang diperbolehkan dari hasil suatu proses

### **❑ Process Condition Table**

adalah Batasan atau spesifikasi kondisi mesin yang diperbolehkan pada saat proses.

# **CONTROL PLAN**

Dokumen pendukung : Refer Control Plan Inlet G08Z - 087A

## NCP application ( Musashi dispenser pressure ML-808FX )

| PROCESS                                    |  | Process Specification | Measurement Technique                | Size    | Freq                        | Pic                               | Control Method   |
|--|--|-----------------------|--------------------------------------|---------|-----------------------------|-----------------------------------|--|
| Temperature of syringe holder 1            |  | 35±0.5 °C             | Monitor check                        | 1 Point | 1 time/shift                | Operator                          | Check sheet (Doc. No. B5-01)                           |
| Temperature of pre-heater No.1             |  | 100±5°C               | Monitor check<br>Surface thermometer | 1 Point | 1 time/shift<br>1 time/week | Prod. Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Temperature of pre-heater No.2             |  | 100±5°C               | Monitor check<br>Surface thermometer | 1 Point | 1 time/shift<br>1 time/week | Prod. Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Temperature of pre-heater No.3             |  | 100±5°C               | Monitor check<br>Surface thermometer | 1 Point | 1 time/shift<br>1 time/week | Prod. Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Temperature of mounting stage NCP dispense |  | 77±5°C                | Monitor check<br>Surface thermometer | 1 Point | 1 time/shift<br>1 time/week | Prod. Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Temperature of pre-heater No.4             |  | 80±5°C                | Monitor check<br>Surface thermometer | 1 Point | 1 time/shift<br>1 time/week | Prod. Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Dispenser Pressure                         |  | 210± 30kPa            | Monitor check                        | 1 Point | 1 time/day                  | Operator                          | Check sheet (Doc. No. B5-01)                           |
| Dispenser Time                             |  | 1.35 s (constant)     | Monitor check                        | 1 Point | 1 time/day                  | Operator                          | Check sheet (Doc. No. B5-01)                           |

## NCP spreading and application ( SMAC LAL35-025-65F )

| PROCESS  |  | Process Specification                   | Measurement Technique                                   | Size                 | Freq                                   | Pic              | Control Method               |
|--|--|---|---|----------------------|--|------------------|------------------------------|
| NCP Receive                                    |  | Keeping quality under < -20°C           | Test report supplier & Data track during transportation | Each lot             | Each lot of the manufacturer (per Lot) | PIC in warehouse | Data keeping                 |
| NCP storage temperature                        |  | < -20°C                                 | Check temperature monitor                               | Point                | 1 time/day                             | Operator         | Check sheet (Doc. No. G5-03) |
| Expire date for use NCP (freezer storage life) |  | 12 months after manufacturing date      | Naked eyes  | Each syringe         | The unit of NCP lot                    | Operator         | Check sheet (Doc. No. B5-06) |
| NCP life Time (after thawing)                  |  | Within 7day after take-out from freezer | Time Control  | Each syringe         | Each syringe                           | Operator         | Check sheet (Doc. No. B5-06) |
| NCP thawing Time                               |  | 1 hour in room temperature              | Time Control  |                      |  |                  |                              |
|  |  | 1 hour in syringe heater                |   | Every change syringe | Every change syringe                   | Operator         | Check sheet (Doc. No. B5-06) |
|  |  | (Total thawing Time 2 hours)            |   |                      |  |                  |                              |
| Temperature syringe heater                     |  | 35±0.5 °C                               | Monitor check   | Every change syringe | Every change syringe                   | Operator         | Check sheet (Doc. No. B5-06) |

## COF Mounting (Chip Pick up)

|   |  |                    |            |         |            |          |                              |
|---|--|--------------------|------------|---------|------------|----------|------------------------------|
| Chip handling /scattering chip→collecting |  | No scattering chip | Naked Eyes | 1 Point | 1 Time/day | Operator | Check sheet (Doc. No. B5-01) |
|---|--|--------------------|------------|---------|------------|----------|------------------------------|

## COF- mounting (ACP application) ( KEYENCE XG-035M )

| PROCESS  |  | Process Specification  | Measurement Technique             | Size          | Freq                 | Pic             | Control Method               |
|--|--|--|-----------------------------------|---------------|----------------------|-----------------|------------------------------|
| Temperature of ACP squeeze stage                     |  | 35°C±5°C   | Monitor check                     | 1 Point       | 1 Time/shift         | Operator        | Check sheet (Doc. No. B5-01) |
|  |  |  | Surface Thermometer               | 1 Point       | 1 Time/week          | Process Control | Check sheet (Doc. No. B5-10) |
| ACP storage temperature                              |  | < -20°C freezer setting - 30°C)  | Check temperature monitor         | Every Syringe | 1 Time/day           | Operator        | Check sheet (Doc. No. G5-03) |
| ACP use-by date (frozen storage life)                |  | Within 12month after manufacturing date  | Visual check                      | Every Syringe | Every Lot or Syringe | Operator        | Check sheet (Doc. No. B5-02) |
| ACP use-by date after thawed                         |  | Within 7days after take-out from freezer and including thawing Time within total 168h                            | Time control                      | Every Syringe | 1 Time/day           | Operator        | Check sheet (Doc. No. B5-02) |
| ACP thawing Time                                     |  | Keep over 1hour under room temperature   | Time control                      | Every Syringe | When change syringe  | Operator        | Check sheet (Doc. No. B5-02) |
| ACP pattern/transcrip check or ACP spreading on bump |  | ACP pattern can see into bump (mean there is ACP) and ACP pattern can't see into the bump (mean there is no ACP) | Monitor/camera check (Monitor #3) | 1 Point       | 1 Time/day           | Operator        | Check sheet (Doc. No. B5-01) |

# COF-mounting (chip mounting) KEYENCE XG-035M

| PROCESS                                       |  | Process Specification   | Measurement Technique  | Size       | Freq                            | Pic                         | Control Method   |
|---|--|---|--|------------|---------------------------------|-----------------------------|--|
| Temperature of temporary press area           |  | 65°C±5°C  | Monitor Check<br>Surface Thermometer                                     | 1 Point    | 1 time / shift<br>1 time / week | Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-01) |
| Temporary press force                         |  | COF#01 (Peak Value) : 4.51N-5.31N<br>COF#02 (Peak Value): 4.11N-4.91N<br>Target : 1.5N ±0.5N  | Actual pressure reading on machine monitor<br><br>Load cell by equipment | 1 Point    | 1 time / day<br>1 time / month  | Operator<br>PE Engineer     | Graph (Doc. No. B5 -01)<br>Graph (Doc. No. B5 -30)     |
| Temperature of mounting head Chip Press 1 & 2 |  | 185°C±5°C   | Monitor check  | All Head   | 1 Time/shift/Every head         | Operator                    | Check sheet (Doc. No. B5-01)                           |
|   |  |   | Surface thermometer  | Every head | 1 Time/shift/Every head         | Process Control             | Graph (Doc. No. B5-10)                                 |
| Temperature of bottom heater Chip Press 1 & 2 |  | 125°C±5°C   | Monitor check<br>Surface thermometer                                     | Every head | 1 Time/shift/Every head         | Operator<br>Process Control | Check sheet (Doc. No. B5-01)<br>Graph (Doc. No. B5-10) |
| Main Press Pressure (Head 1 and 2)            |  | COF#01 :<br>H1 : (Peak value): 6.20N - 6.54N<br>(Valley Value) : 6.20 - 6.52<br>H2 : (Peak value): 5.25N-6.15N<br>(Valley Value) : 5.30 - 6.10<br><br>COF#02<br>H1 : (Peak value) : 5.71 - 6.01 N<br>(Valley Value) : 5.66 - 5.96<br>H2 : (Peak value): 6.05N-6.35N<br>(Valley Value) : 6.00 - 6.30 | Actual pressure reading on machine monitor                               | 1 Point    | 1 Time/day                      | Operator                    | Graph (Doc. No. B5-01)                                 |
|   |  | 2.2N ±0.5N  | Load cell by equipment   | 1 Point    | 1 Time/month                    | PE. Engineer                | Graph (Doc. No. B5-030)                                |
| Carring teflon tape                           |  | No run off (no empty)   | Visual check   | Every day  | 1 Time/day and Every change     | Operator                    | Check sheet (Doc. No. B5-01)                           |
|   |  | No Jamming  |  |            |                                 |                             |  |

## COF mounting (Plate mounting) Mushasi dispenser pressure ML-808FX

| PROCESS                              |  | Process Specification  | Measurement Technique | Size    | Freq         | Pic             | Control Method              |
|--------------------------------------|--|------------------------|-----------------------|---------|--------------|-----------------|-----------------------------|
| Temperature of syringe holder heater |  | 35°C±2°C               | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
| Temperature of pre-heater No.5       |  | 55°C ± 5°C             | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
|                                      |  |                        | Surface Thermometer   |         | 1 Time/week  | Process Control | Graph (Doc. No. B5-14)      |
| Temperature of pre-heater No.6       |  | 55°C ± 5°C             | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
|                                      |  |                        | Surface Thermometer   |         | 1 Time/week  | Process Control | Graph (Doc. No. B5-14)      |
| Temperature of pre-heater No.7       |  | 55°C ± 5°C             | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
|                                      |  |                        | Surface Thermometer   |         | 1 Time/week  | Process Control | Graph (Doc. No. B5-14)      |
| Temperature of glass dispense area   |  | 55°C ± 5°C             | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
|                                      |  |                        | Surface Thermometer   |         | 1 Time/week  | Process Control | Graph (Doc. No. B5-14)      |
| Temperature of glue mounting area    |  | 55°C ± 5°C             | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |
|                                      |  |                        | Surface Thermometer   |         | 1 Time/week  | Process Control | Graph (Doc. No. B5-14)      |
| Temperature (after heat) No.8        |  | OFF (Room Temperature) | Monitor check         | 1 Point | 1 Time/shift | Prod. Operator  | Checksheet (Doc. No. B5-04) |



## COF mounting (Plate mounting) Mushasi dispenser pressure ML-808FX

| PROCESS                        |  | Process Specification                                    | Measurement Technique          | Size        | Freq                  | Pic            | Control Method               |
|--------------------------------|--|--|--------------------------------|-------------|-----------------------|----------------|------------------------------|
| Dispenser Pressure             |  | 80 kPa ~ 140 kPa   | Monitor check                  | 1 Point     | 1 Time/ Shift         | Prod. Operator | Checksheet (Doc. No. B5-04)  |
| Glue Receive                   |  | < -20°C Freezer setting - 30°C                           | Testing report by manufacturer | 1 Point     | Every lot             | Operator       | -                            |
| Glue storage temperature       |  | < -20°C Freezer setting - 30°C                           | Monitor check                  | 1 Point     | 1 Time/day            | Operator       | Check sheet (Doc. No. G5-03) |
| Freezer Storage Life           |  | Within 8 months after Product                            | Naked eyes                     | Every lot   | Every Lot and Syringe | Operator       | Checksheet (Doc. No. B5-05)  |
| Glue use by date after thawing |  | Within 7day after take-out from freezer                  | Time control                   | 1 Point     | 1 Time/day            | Operator       | Checksheet (Doc. No. B5-05)  |
| Glue thawing Time              |  | 1 hour in room temperature                               | Time control                   | All Machine | When change syringe   | Operator       | Checksheet (Doc. No. B5-05)  |
|                                |  | 1 hour in syringe heater<br>(Total thawing Time 2 hours) |                                |             |                       |                |                              |

**COF mounting (Plate mounting Condition)****KEYENCE XG-200M**

| PROCESS                     |  | Process Specification                | Measurement Technique | Size         | Freq         | Pic      | Control Method                   |
|-----------------------------|--|--------------------------------------|-----------------------|--------------|--------------|----------|----------------------------------|
| Temporary Press temperature |  | OFF (Room Temperature)               | Monitor check         | 1 Point      | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04)      |
| Carring teflon tape         |  | No jamming<br>No runn off (No empty) | Visual Check          | Each Machine | 1 Time/day   | Operator | Checksheet (Doc. No. B5-04)      |
| Glue Filet (Overflow)       |  | Reject Criteria<br>Visual Inspection | Visual check          | 1 Point      | 1 Time/day   | Operator | Checksheet (Doc. No. G12K5-001A) |
| Backstage vacuum pressure   |  | -50kPa ~ -60kPa                      | Visual check          | Every Lot    | 1 Time/day   | Operator | Checksheet (Doc. No. B5-04)      |

## COF Mounting (inline cure) COF Mounter

| PROCESS                          |  | Process Specification  | Measurement Technique | Size           | Freq         | Pic      | Control Method              |
|----------------------------------|--|--|-----------------------|----------------|--------------|----------|-----------------------------|
| Space Temperature Heater Block 1 |  | COF#01 : $92\pm5^{\circ}\text{C}$ /<br>COF#02 : $92\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 2 |  | COF#01 : $82\pm5^{\circ}\text{C}$ /<br>COF#02 : $90\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 3 |  | COF#01 : $85\pm5^{\circ}\text{C}$ /<br>COF#02 : $87\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 4 |  | COF#01 : $87\pm5^{\circ}\text{C}$ /<br>COF#02 : $81\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 5 |  | COF#01 : $83\pm5^{\circ}\text{C}$ /<br>COF#02 : $87\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 6 |  | COF#01 : $83\pm5^{\circ}\text{C}$ /<br>COF#02 : $85\pm5^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Space Temperature Heater Block 7 |  | COF#01 : $80\pm5^{\circ}\text{C}$ /<br>COF#02 : $80\pm10^{\circ}\text{C}$  | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 1/ Upside           |  | COF#01 : $103\pm2^{\circ}\text{C}$ /<br>COF#02 : $101\pm2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 1/ Downside         |  | COF#01 : $102\pm2^{\circ}\text{C}$ /<br>COF#02 : $101\pm2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 2/ Upside           |  | COF#01 : $95\pm2^{\circ}\text{C}$ /<br>COF#02 : $95\pm2^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 2/ Downside         |  | COF#01 : $104\pm2^{\circ}\text{C}$ /<br>COF#02 : $100\pm2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 2/ Downside         |  | COF#01 : $100\pm2^{\circ}\text{C}$ /<br>COF#02 : $90\pm2^{\circ}\text{C}$  | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |

| PROCESS                    |  | Process Specification  | Measurement Technique | Size           | Freq         | Pic      | Control Method              |
|----------------------------|--|--|-----------------------|----------------|--------------|----------|-----------------------------|
| Heater Block 3/Upside      |  | COF#01 : $100\pm 2^{\circ}\text{C}$ /<br>COF#02 : $90\pm 2^{\circ}\text{C}$  | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 3/ Downside   |  | COF#01 : $157\pm 2^{\circ}\text{C}$ /<br>COF#02 : $165\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 3/ Middleside |  | COF#01 : $157\pm 2^{\circ}\text{C}$ /<br>COF#02 : $160\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 4/ Upside     |  | COF#01 : $100\pm 2^{\circ}\text{C}$ /<br>COF#02 : $98\pm 2^{\circ}\text{C}$  | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 4/ Downside   |  | COF#01 : $90\pm 2^{\circ}\text{C}$ /<br>COF#02 : $97\pm 2^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 5/ Upside     |  | COF#01 : $110\pm 2^{\circ}\text{C}$ /<br>COF#02 : $125\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 5/ Downside   |  | COF#01 : $150\pm 2^{\circ}\text{C}$ /<br>COF#02 : $175\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 5/ Middleside |  | COF#01 : $150\pm 2^{\circ}\text{C}$ /<br>COF#02 : $165\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 6/ Upside     |  | COF#01 : $105\pm 2^{\circ}\text{C}$ /<br>COF#02 : $103\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 6/ Downside   |  | COF#01 : $95\pm 2^{\circ}\text{C}$ /<br>COF#02 : $92\pm 2^{\circ}\text{C}$   | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 7/ Upside     |  | COF#01 : $105\pm 2^{\circ}\text{C}$ /<br>COF#02 : $103\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |
| Heater Block 7/ Downside   |  | COF#01 : $105\pm 2^{\circ}\text{C}$ /<br>COF#02 : $103\pm 2^{\circ}\text{C}$ | Monitor check         | Each Equipment | 1 Time/shift | Operator | Checksheet (Doc. No. B5-04) |

## Oven Cure (oven Bake) after COF-mounting

ESPEC PH 201M

| PROCESS               |  | Process Specification | Measurement Technique | Size             | Freq             | Pic         | Control Method                  |
|-----------------------|--|-----------------------|-----------------------|------------------|------------------|-------------|---------------------------------|
| Setting Temperature   |  | 100±5°C               | Monitor check         | 1 Point          | 1 Time/day       | Operator    | Checksheet (Doc. No. H5-01)     |
| Chamber Appearance    |  | No dirty/ FM          | Visual check          | All chamber room | 1 Time/ day      | BM Tech     | Checksheet (Doc. No. G10K-189A) |
| Measuring Temperature |  | 100±5°C               | Temperature recorder  | Each Machine     | 1 Time/ 6 months | QC Engineer | Graph                           |
| Curing Time           |  | 80 minutes            | Timer                 | Every products   | All products     | Operator    | Checksheet (Doc. No. H5-01)     |

## Visual Inspection

| PROCESS                    | Item check                   |  | Process Specification             | Measurement Technique | Size      | Freq         | Pic      | Control Method |
|----------------------------|------------------------------|--|-----------------------------------|-----------------------|-----------|--------------|----------|----------------|
| <b>Visual Inspection 1</b> | NCP Void                     |  | Reject Criteria Visual Inspection | Visual check          | Every day | All Products | Operator | GPRISM System  |
|                            | NCP Filling (Insufficient)   |  |                                   |                       |           |              |          |                |
|                            | Bump Mark                    |  |                                   |                       |           |              |          |                |
| INLET INSPECTION           | Bump Position                |  |                                   |                       |           |              |          |                |
|                            | Contamination                |  |                                   |                       |           |              |          |                |
|                            | Foreign Material             |  |                                   |                       |           |              |          |                |
| <b>Visual Inspection 2</b> | Glue Void                    |  | Reject Criteria Visual Inspection | Visual check          |           |              |          | GPRISM System  |
|                            | Glue Filet                   |  |                                   |                       |           |              |          |                |
| INLET INSPECTION           | Glue Filling (Insufficient)  |  |                                   |                       | Every day | All products | Operator |                |
|                            | Support Plate Position       |  |                                   |                       |           |              |          |                |
|                            | Foreign Material             |  |                                   |                       |           |              |          |                |
| <b>Visual Inspection 3</b> | Scratch on capasitor pattern |  | Reject Criteria Visual Inspection | Visual check          | Every day | All products | Operator | GPRISM System  |
|                            | Contamination on sheet       |  |                                   |                       |           |              |          |                |
|                            | Foreign Material on sheet    |  |                                   |                       |           |              |          |                |
| INLET INSPECTION           | Wrinkle sheet                |  |                                   |                       |           |              |          |                |
|                            | Blocking Bristle/pattern     |  |                                   |                       |           |              |          |                |
|                            | Breaking Mark on sheet       |  |                                   |                       |           |              |          |                |
|                            | NG label position            |  |                                   |                       |           |              |          |                |
|                            | Push Mark                    |  |                                   |                       |           |              |          |                |
|                            | Silver Paste                 |  |                                   |                       |           |              |          |                |
|                            |                              |  |                                   |                       |           |              |          |                |

## Final Test (F-Test)

| PROCESS  |  | Process Specification | Measurement Technique | Size           | Freq         | Pic      | Control Method              |
|--|--|-----------------------|-----------------------|----------------|--------------|----------|-----------------------------|
| Voltage value of stabilized power supply               |  | 28.0V~28.5V           | Monitor check         | All test stage | 1 Time/month | TM Eng.  | Checksheet (Doc. No. B5-26) |
| RF (communication test)                                |  | Pass rate 100/100 OK  | Tester                | All test stage | 1 Time/month | TM Eng.  | Checksheet (Doc. No. B5-26) |
| Accuracy of communication test (Standard sample Check) |  | Standard sample unit  | Tester                | Every month    | 1 Time/month | TM Eng.  | Checksheet (Doc. No. B5-26) |
| RF/Test program check                                  |  | Name of program       | Check Lot sheet       | Every lot      | 1 Time/Lot   | Operator | Checksheet (Doc. No. D5-01) |

## Finishing 530 (Inlet Finishing Machine)

| PROCESS                       |  | Process Specification  | Measurement Technique                           | Size         | Freq                    | Pic             | Control Method                    |
|-------------------------------|--|--|---|--------------|-------------------------|-----------------|-----------------------------------|
| Direction of reel             |  | Label side in front  | Visual check                                    | Every reel   | 1 Time/reel             | Operator        | Checksheet (Doc. No. E5-02)       |
| Checking Program              |  | Program D-Test : For Mass Production<br>Program IDDD : For Re Process<br>Program No use MP : For Buy off Process | Monitor Check                                   | 1 point      | Every lot               | Operator        | Checksheet ( Doc No. G12K5-002A ) |
| Checking of Serial / PUPI no. |  | Serial no. must be sequence  | Monitor Check                                   | 2 Pcs        | Every lot               | Operator        | Checksheet ( Doc No. G12K5-002A ) |
| End tape position             |  | Length of end tape position (according to WPI)   | Measure (Ruler)                                 | All product  | Every dummy replacement | Operator        | Checksheet (Doc. No. E5-01)       |
|                               |  |  | Verification (measure) dummy replacement result |              |                         | Process Control |                                   |
| Sample                        |  | Reject Criteria Visual Inspection  | Visual check                                    | Every sample | Every lot               | Operator        | Checksheet (Doc. No. D5-01)       |



## Packing

| PROCESS                                   |  | Process Specification  | Measurement Technique | Size              | Freq              | Pic          | Control Method                                    |
|---|--|--|-----------------------|-------------------|-------------------|--------------|---|
| -Quantity (2700 -3700 pcs)                |  | To check and match between type/device name and lot-sheet      | Naked eye             | Each packing unit | Each packing unit | Operator     | Checksheet (Doc. No. F5-01)                       |
| -Type/Device name                         |  |  |                       |                   |                   |              |   |
| -Aluminium Bag / Outer box labeling. Etc. |  |  |                       |                   |                   |              |   |
| Control of product (function control)     |  | Reject qty of appearance, shipping qty, fraction inventory qty | Naked eye             | 1 point           | 1 Time/day        | Operator     | Product control table and function inventory slip |
| Self Life                                 |  | Shipment within 1 year   | SAP system auto lock  | All product       | Every shipment    | FG Warehouse | SAP System auto lock (Doc. No. G15C-001)          |
| Room temperature/ Hummidity               |  | 25 ± 3°C<br>50 ± 10% R.H                                       | Thermo-hygrograph     | 1 Area            | 1 time/day        | FG Warehouse | Doc.No.G15K-004B                                  |

